
#### TOHATSU OUTBOARD MOTORS

# T PARTS LIST

### RC5

リモートコントロール ボックス REMOTE CONTROL BOX



## トーハツ株式会社 TOHATSU CORPORATION

OB NO. 002-21024-4 0808 M 3000 Copyright © 2008 Tohatsu Corporation. All rights reserved. No part of this manual may be reproduced or transmitted in any form or by any means without the express written permission of Tohatsu Corporation.


Tohatsu Corp. makes no warranty, express or implied, regarding the use of this data. Tohatsu Corp. assumes no responsibility for errors or omissions nor assumes any liability for damages resulting from the use of the information contained herein. In some cases a part design may have changed since this manual was published or may not apply to your particular engine model, or a service/parts bulletin may have been issued containing important information pertaining to this model and/or a particular part. Some parts may be serial number and/or model number specific. You are strongly advised to contact your local dealer to ensure the accuracy of the data contained in this manual applies to your particular model and serial number.

#### パーツリストのご使用について

- 1. このパーツリストはリモートコントロールボックス (RC5) を構成 している部分を集録したものであります。
- 2. 部品番号について

部品番号は11桁で構成されており、一般部品と市販部品は次の様に 表示されています。

#### 一般部品 (純正)



- 3. 部品の新設、廃止または変更が生じた場合は、サービスインフォメーションにてお知らせ致しますので、その都度、ご訂正下さい。
- 4. アッセンブリでの販売部品は、その構成する部品の頭に(\*)印をつけて表わしています。
- このリモートコントロールボックス(RC5)の適用モデルは次の通りです。


型式	適 用 モ デ ル
RC5A	MFS25B/30B, M40D2~90A PTT付に対応
RC5B	MFS9.9C~30B, M40D2~90A セル付、PTT付なしに対応
RC5C	MFS8A3/9.8A3, M8B~40C セル付きに対応
RC5D	MFS5B~F30B, M4C~40C セルなしに対応
RC5E	M120A2/140A2に対応
RC5F	MD40B~115A (TLDI) に対応

#### HOW TO USE THIS PARTS LIST

- 1. This parts list contains remote control box (RC5 type).
- 2. Part numbering system:

Part number consists of 11 digits, and indicates a genuine Tohatsu parts or a commercially available parts as follows.

Genuine Tohatsu part:




- Please keep the Parts List updated each time when receiving the Service Bulletin describing the addition, abolition and/or change of parts.
- Number of part to be sold in the form of assembly is prefixed with (\*) mark.
- The following models are applicable to the RC5 type remote control box.

Туре	Applicable model
RC5A	MFS25B/30B, M40D2-90A with PTT
RC5B	MFS15C-30B, M40D2-90A without PTT
RC5C	MFS8A3/9.8A3, M8B-40C with electric starter
RC5D	MFS5B-30B, M4C-40C without electric starter
RC5E	M120A2/140A2
RC5F	MD40B-115A (TLDI)

#### 目 次 CONTENTS


		page
Fig.1	シングル リモコンボックス SINGLE REMOTE CONTROL BOX	1
Fig.2	リモコンボックスの構成部品 COMPONENT PARTS OF REMOTE CONTROL BOX ASS'Y	5
Fig.3	リモコンボックスの構成部品(電装品関係) COMPONENT PARTS OF REMOTE CONTROL BOX ASS'Y (ELECTRICAL PARTS)	9
Fig.4	ケーブル CABLE ······	11

シングル リモコンボックス Fig. 1 SINGLE REMOTE CONTROL BOX




見出番号	部品番号	部 品 名		_	_	Q'		備考
- э — д - Ј	нинн ш.7	ни ни та	R	R	R	R	RF	VIII 75
	1		C	С	С	С	clo	;
Ref. No.	Part No.	Description	5	5	5	5	5   5	Remarks
			F	E	200	190	c D	[1] [1] [2] [2] [2] [2] [2] [2] [2] [2] [2] [2
55 Galf		リモートコントロールホックスアッシ (RC5A)	47		U		T	
1-1	3B7Q84330-2	Remote Control Box Ass'y (RC5A)			1	4	+	
1-1-1	242-04275-0	スクリュ	1	9				
1-1-1	3A3-84375-0	⊼^°−₩	+		3	+	+	
1-1-2	3A3-84374-0	1000			3			
	010710	ワッシャ	+		-	+	+	
1-1-3	353-84371-0	* Washer			3			
n ven re		ナット						
1-1-4	930103-0600	* Nut			3			
		ターミナルアイ						
1-1-5	3A3-83314-2	* Terminal Eye		_	2	+	+	
1-1-6	945303-0600	E リング、d=6 * E-Ring, d=6			2			
1 1 0	545505-0000	↑ E-Ring, α-6	+	-	4	+	+	
1-1-7	3A3-84376-0	15 (2.14) 7 (5)			1		1	
	0.070 0	リモートコントロールホックスアッシ (RC5B)		$\dashv$	+	+	+	
1-2	3B7Q84340-2	Remote Control Box Ass'y (RC5B)				1		
		スクリュ			7		T	
1-2-1	3A3-84375-0					3		
	040 04074	スペーサ						
1-2-2	3A3-84374-0	* Spacer	+	-	4	3	+	
1-2-3	353-84371-0	ワッシャ * Washer	11			3		1
1 2 3	000 040/1-0	ナット	+	-	+	3	+	-
1-2-4	930103-0600	* Nut				3		1
		ターミナルアイ	11	$\dashv$	$\forall$	Ť	+	
1-2-5	3A3-83314-2	* Terminal Eye				2		
- 57 - 260 - 124100		E リング、 d=6		$\neg$	$\neg$		T	
1-2-6	945303-0600	* E-Ring, d=6	$\perp$			2		
107	040 04070 0	クプロメット		- 1		.		
1-2-7	3A3-84376-0	* Grommet ケーフ・ルターミナルフ・ラク・	+	$\dashv$	+	1	+	
1-2-8	353-76037-0	* Cable Terminal Plug				2		
120	000 70007 0	リモートコントロールホークスアッシ (RC5C)	+	+	+	4	+	
1-3	3B7Q84350-3	Remote Control Box Ass'y (RC5C)						
		スクリュ	$\Box$	$\neg$	$\dashv$	$\top$		
1-3-1	3A3-84375-0					_ (		
	040 040-	スペーサ		T				
1-3-2	3A3-84374-0		+		_	_ (	-	
1-3-3	353-84371-0	ワッシャ * Washer						
1 0 0	333-04371-0	+ wasner +yh	+	+	+	+	+	
1-3-4	930103-0600	* Nut				;		
		ターミナルアイ	+	1	1	+	-	
1-3-5	3A3-83314-2	* Terminal Eye				2		
W 25 DV	6256737-76 107-2153	E リング、d=6	$\top$					
1-3-6	945303-0600	* E-Ring, d=6	$\perp$			1		
	010 010	ク・ロメット			T			
1-3-7	3A3-84376-0		$\perp$	_	1	- 7	-	
1-2-0	242-76007 0	ケープ・ルターミナルフ・ラク・						
1-3-8	SAS-/003/-0	* Cable Terminal Plug グロメット B	+	+	+	1	-	
1-3-9	361-84415-0	* Grommet "B"						
	001 04410-0	ク <sup>®</sup> ロメット A	+	+	+	-	+	-
1-3-10	361-84414-0	* Grommet "A"						
		リモートコントロールホックスアッシ (RC5D)	+	+	+		+	
1-4	3B7Q84360-1	Remote Control Box Ass'y (RC5D)					1	
		スクリュ						
1-4-1	3A3-84375-0	* Screw	1 1				3	l .

シングル リモコンボックス Fig. 1 SINGLE REMOTE CONTROL BOX




見出番号	部品番号	部 品 名			_	Q'	_		備考
		nc nn H	R	R		R	- 1		PER -J
	Age to the		C	C			C	C	20
Ref. No.	Part No.	Description	5 F	5 E	5		- 1	5 D	Remarks
		スペーサ		-	A	Б	-		
1-4-2	3A3-84374-0	* Spacer	_			4	4	3	
1-4-3	353-84371-0	* Washer						3	
1-4-4	930103-0600	ナット * Nut						3	
10 10 10 10 10		ターミナルアイ				$\exists$	7		
1-4-5	3A3-83314-2	E リング、d=6	+	$\dashv$		$\dashv$	+	2	
1-4-6	945303-0600	* E-Ring, d=6 グロメット	-			-	-	2	
1-4-7	3A3-84376-0	* Grommet						1	
1-4-8	369-84416-0	ケーレット C * Grommet "C"						1	
W W Keek II		グロメット D				1	7		
1-4-9	353-84321-0	* Grommet "D" グロメット A	+	-		+	+	1	
1-4-10	361-84414-0	* Grommet "A" グロメット E	+			+	4	1	
1-4-11	369-84418-0	* Grommet "E"						1	
1-5	3C7Q84370-2	リモートコントロールホ*ックスアッシ(RC5E) Remote Control Box Ass'y (RC5E)		1					
		スクリュ	$\top$				$\top$	7	
1-5-1	3A3-84375-0	* Screw	+	3		+	+	+	
1-5-2	3A3-84374-0	* Spacer ワッシャ	+	3		+	4	4	
1-5-3	353-84371-0	* Washer		3					
1-5-4	930103-0600	ナット * Nut		3					
1-5-5	3A3-83314-2	ターミナルアイ	П	2			1		
0		E リング、d=6	+	$\neg$		+	+	+	
1-5-6	945303-0600	* E-Ring, d=6 グロメット	+	2	-	+	+	+	
1-5-7	3A3-84376-0	* Grommet	$\perp$	1			_		
1-6	3T5Q84500-1	リモートコントロールボックスアッシ(RC5F) Remote Control Box Ass'y (RC5F)	1						
1-6-1	3A3-84375-0	スクリュ	3		$\exists$		1		
		スペーサ		$\dashv$		+	+	+	
1-6-2	3A3-84374-0	* Spacer ワッシャ	3	$\dashv$	_	$\dashv$	+	+	0-1-2-55
1-6-3	353-84371-0	* Washer	3			_	_	$\downarrow$	
1-6-4	930103-0600	ナット * Nut	3						
-W = M - 2002	Market Control of the Control of the Control	ターミナルアイ * Terminal Eye	2				1	$\dashv$	
1-6-5	3A3-83314-2	E リング、d=6		+		+	+	+	
1-6-6	945303-0600	* E-Ring, d=6 ク*ロメット	2	-	-	+	+	+	
1-6-7	3A3-84376-0		1	-		+	1	-	
						_	1	1	
							7	$\exists$	

#### リモコンボックスの構成部品 Fig. 2 COMPONENT PARTS OF REMOTE CONTROL BOX ASS'Y




見出番号	部品番号	部 品 名		,	個對	_	_	_	備考
		er en e	R	R	R	R	R	R	Nu and
			c	C	C	С	C	С	
Ref. No.	Part No.	Description	5	5	5	5	5	5	Remarks
			F				c		rtomanto
		シフトキ・ヤアッシ	- 1	1-	· ·	-	Ŭ	_	
2-1	3A3-84381-0	Shift Gear Ass'y	1	1	1	1	1	1	
	0,10 0,100,1 0	ブッシング B		+	†÷	Ė	r'	Ė	
2-2	3A3-84432-0	Bushing "B"	1	1	1	1	1	1	
		スロットルフリクションアーム		Ť	i i	Ė	-	Ť	
2-3	3A3-84428-0	Throttle Friction Arm	1	1	1	1			
		ワッシャ							
2-4	3A3-84383-0	Washer	1	1	1	1	1	1	
-040000		ト'ライフ'キ'ヤ	J.,	J.,	Ü.,				
2-5	3A3-84364-2	Drive Gear	1	1	1	1	1	1	
202	202020000000000000000000000000000000000	ブッシンク゛A	102						
2-6	3A3-84431-0	Bushing "A"	2	2	2	2	2	2	
	040 04400 0	スラストプレート							
2-7	3A3-84422-0	Thrust Plate	1	1	1	1	1	1	
2-8	3A3-84421-0	Roller	1	4	1	1	,	,	
2 0	0/10 04421-0	スロットルアーム			1	-1	1	-	
2-9	3A3-84365-1	Throttle Arm	1	1	1	1	1	1	
	27.00 0 1000 1	テ・テントローラ	- 1	<u> </u>	·	H	+	÷	
2-10	353-84388-0	Detent Roller	1	1	1	1	1	1	
		デ <sup>*</sup> テントスプ <sup>*</sup> リング <sup>*</sup>		Ė					
2-11	3A3-84307-0	Detent Spring	5	5	5	5	5	5	
		<del>デ</del> テントリテーナ						П	
2-12	3A3-84423-0	Detent Retainer	1	1	1	1	1	1	
		スクリュ							
2-13	921503-0406	Screw	1	1	1	1	1	1	
2-14	010102-0525	ホ*ルト Bolt	-   -				.	4	
2 14	910103-0525	ナット	1	1	1	1	1	1	
2-15	930103-0500	Nut	1	1	1	1	1	1	
		コントロールレバー	-1	Ė	Ė	·			
2-16	3B7Q84343-0	Control Lever	1	1	1	1	1	1	
		グリップ							
2-17	3A3-84404-0	Grip	1	1	1	1	1	1	
	001500 0510	スクリュ				Ų.	.		
2-18	921503-0510	Screw ニュートラルロックアーム	1	1	1	1	1	1	
2-19	3A3-84401-0	Neutral Lock Arm	1	1	1	1	٠,	1	
2 10	070 04401 0	ニュートラルロックスフ・リンク		-	+	-	-	-	
2-20	3A3-84403-0	Neutral Lock Spring	1	1	1	1	1	1	
		スクリュ	+	<u> </u>	H	Ė	+		
2-21	921503-0510	Screw	1	1	1	1	1	1	
A SUBJEMENT	NOTE HER WOOD THE COURT OF THE COURT	ロックアームワッシャ							
2-22	3A3-84407-0	Lock Arm Washer	1	1	1	1	1	1	
2002	AND TAXABLE VIOLEN	チルトスイッチカバー		100	1		X2.		
2-23	3A3-84451-0	Tilt Switch Cover	1	1	1	1	1	1	
2_24	242-04450-0	チルトスイッチプラク <sup>*</sup>		,			اړ		
2-24	3A3-84452-0	Tilt Switch Plug ポルト	1	1	1	2	2	2	
2-25	3A3-84442-0	かた Bolt	,	1	1	1	,	,	
2 20	JA3-0444Z-U	ワッシャ	- 1	1	1	1	-	1	
2-26	940103-0800	Washer	1	1	1	1	1	1	
	- 10.00 0000	リヤハウシ・ング	+	-	-	-	+	•	
2-27	3B7Q84441-0	Rear Housing	1	1	1	1	1	1	
		フリースロットルレハー	-1	Ė		İ			
2-28	3B7Q84312-0	Free Throttle Lever	1	1	1	1	1	1	
		ブッシング E							
2-29	3A3-84435-0	Bushing "E"	1	1	1	1	1	1	
		フリースロットルト・ラム							
2-30	3A3-84391-0	Free Throttle Drum	1 1	1	1	1	1	1	

#### リモコンボックスの構成部品 Fig. 2 COMPONENT PARTS OF REMOTE CONTROL BOX ASS'Y




見出番号	部品番号	部 品 名				Į Q			備考
九四田勺	HPHH TH TO		R			R		R	川 有
			С	C				С	
Ref. No.	Part No.	Description	5	5				5	Remarks
	i are No.	Description	F	E	A		C	D	Remarks
		ウェーフ・ワッシャ	-	-	^	-	-		
2-31	3A3-84368-0	Wave Washer	1	1	1	1	1	1	
		スクリュ							
2-32	921603-0512	Screw	2	2	2	2	2	2	
0.00		ローラリテーナ					20	- 3	
2-33	3A3-84426-0	Roller Retainer フリースロットルローラ	1	1	1	1	1	1	
2-34	3A3-84424-0	Free Throttle Roller	1	1	1	1	1	1	
2 01	070 04424 0	フリースロットルスプリンク	+	-	1	1	-	1	
2-35	3A3-84425-0	Free Throttle Spring	1	1	1	1	1	1	
50 200		スクリュ							
2-36	921503-0406	Screw	1	1	1	1	1	1	
0.07	007004000	リヤハ゜ネル							
2-37	3B7Q84366-0	Rear Panel	1	1	1	1	1	1	
2-38	921603-0518	スクリュ Screw	5	5	_	F	F	5	
2 00	021003-0018	ケープルカバー	5	J	J	0	5	0	
2-39	3A3-84429-0	Cable Cover	1	1	1	1	1	1	
		スロットルフリクションアシ・ャストスクリュ	1			Ì	Ė		
2-40	3A3-84427-0	Throttle Friction Adjusting Screw	1	1	1	1			
		ワッシャ					7	T	
2-41	353-84394-0	Washer	1	1	1	1		$\perp$	
2-42	045303-0600	E リング、d=6		,	,	4		ı	
L-4L	945303-0600	E-Ring, d=6 ロックアームプレート	-1	1	1	1	$\dashv$	-	1 -1(1-
2-43	3A3-84406-0	Lock Arm Plate	1	1	1	1	1	1	
			<u> </u>	÷		+	$\dashv$	1	
						$\Box$	$\Box$		
					_		_		
			+		$\dashv$	-	$\dashv$	$\dashv$	
			$\top$		$\dashv$	$\forall$	$\dashv$		
					$\Box$		$\Box$		
					1	T	Ī	T	
			$\dashv$	$\Box$	$\dashv$	-	4	$\dashv$	
			+	$\dashv$	$\dashv$	$\dashv$	$\dashv$	-	
				$\dashv$	1	1	$\dashv$	$\dashv$	
					1		1		
						$\perp$		$\perp$	
			+	$\dashv$	$\dashv$	+	$\dashv$	$\dashv$	
				+	$\dashv$	+	$\dashv$	$\dashv$	
			$\neg$	$\neg$	$\dashv$	$\forall$	7	$\neg$	
				П	$\neg$	$\top$	1	$\Box$	
						1	_	$\perp$	
			-	$\perp$	4	-	4	4	

# リモコンボックスの構成部品(電装品関係) Fig. 3 COMPONENT PARTS OF REMOTE CONTROL BOX ASS'Y (ELECTRICAL PARTS)



見出番号	部品番号	部 品 名		_	_	ţ Q			備考
			R	1000	10000	R		10.2	
D 6 N	D	D	C	1000	С	1000	C	100	
Ref. No.	Part No.	Description	5	10000	5	3.00	5	5	Remarks
		メインスイッチ	F	E	A	В	С	D	
3-1	353-76020-3	Main Switch	1	1	1	1	1		
		メインスイッチキー (No.301)							
3-1-1	3F3-76217-0	* Main Switch Key (No.301) メインスイッチキー (No.302)	2	2	2	2	2		
	3F3-76218-0	* Main Switch Key (No.302)	2	2	2	2	2		
		メインスイッチキー (No.303)							
	3F3-76219-0	* Main Switch Key (No.303) コート・アッシ B	2	2	2	2	2		
3-2	3A3-76115-0	Cord Ass'y "B"			1	1			
		コート・アッシ B							L=6200
3-3	3C7-76115-0	Cord Ass'y "B" コート・アッシ B	_	1	Ш	_	Щ	_	2 0200
3-4	3T5-76115-0	Cord Ass'y "B"	1						
		コート・アッシ	1						Les regeneres
3-5	361-76110-1	Cord Ass'y ストップ スイッチ	-				1		L=4700
3-6	3A3-06830-0	Stop Switch	1	1	1	1	1		
		ストップ。スイッチ	Ť	Ť		İ	Ė	П	
	398-06830-0	Stop Switch ストップ・スイッチロック(ローフ・付)	1					1	
3-6-1	353-06821-0	* Stop Switch Lanyard	1	1	1	1	1	1	
		PTT スイッチ		Ė	Ħ	İ	Ė	İ	
3-7	3A3-72560-0	"PTT" Switch	1	1	1				
3-8	3A3-72591-0	PTT スイッチカバー "PTT" Switch Cover	1	1	1				
*********		スクリュ							
3-9	921503-0206	Screw オーバーヒートプサー	2	2	2			_	
3-10	3C8-76171-0	オーハーピードブサー Over-Heat Buzzer	1	1	1	1			
VII. V. V. V. V. V. V. V. V. V. V. V. V. V.	retirates management was	ニュートラルスイッチ			Ť	Ì			
3-11	3T5-76086-0	Neutral Switch ニュートラルスイッチ	1			-	_	-	
3-12	3A3-76086-1	Neutral Switch		1	1	1	1		
MI 17-100		スクリュ							
3-13	921503-0315	Screw アシストコート (レット)	2	2	2	2	2	_	
3-14	353-72546-0	Assist Cord (Red)	1	2	1				
		リート・ワイヤハント							
3-15	3A3-84398-0	Lead Wire Band デカル (レバー)	2	2	2	2	2		
3-16	3N5-84331-0	Decal (Lever)	1	1	1	1	1	1	
	research verse se	デカル (トーハツ)							W 20-200-20-11-0-20-2
3-17	3N5-84333-0	Decal (TOHATSU) シフトホ°シ`ションテ`カル	1	1	1	1	1	1	
3-18	3N5-84336-0	Shift Position Decal	1	1	1	1	1	1	
		シフトポジションサイト、テ゛カル							
3-19	3N5-84465-0	Shift Position Side Decal	1	1	1	1	1	1	
		1111411 Wat a 200 a 200 a 200 a 200 a 200 a 200 a 200 a 200 a 200 a 200 a 200 a 200 a 200 a 200 a 200 a 200 a							
-			+			-	_	_	
			$\top$			1			
			+			-	_		

ケーブル Fig. 4 CABLE



見出番号	部品番号	部 品 名		1	固娄	ţ Q	'ty		備考	
元山田与	中四田石	np nn 12	R	R	R	R	R	R	1 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7	
	1		C	C	C	C	C			
Ref. No.	Part No.	Description						I I	Description	
Ret. No.	Part No.	Description	5		5	5	5		Remarks	
			F	E	Α	В	C	D		
		コントロールケープル(7フィート)								
4-1	3A3-83741-0	Control Cable ( 7 Feet)	2	2	2	2	2	2		
		コントロールケープル (8 フィート)								
	3A3-83742-0	Control Cable (8 Feet)	2	2	2	2	2	2		
		コントロールケープル (9 フィート)							Ģ.	
	3A3-83743-0	Control Cable ( 9 Feet)	2	2	2	2	2	2		
		コントロールケープル (10フィート)								
	3A3-83744-0	Control Cable ( 10 Feet)	2	2	2	2	2	2		
		コントロールケープル (11フィート)								
	3A3-83745-0	Control Cable (11 Feet)	2	2	2	2	2	2	V	
		コントロールケープル (12フィート)						-		
	3A3-83746-0	Control Cable (12 Feet)	2	2	2	2	2	2		
	0710 00710 0	コントロールケープル (13 フィート)	+-	-	-	-	-	-		
	3A3-83747-0	Control Cable (13 Feet)	2	2	2	2	2	2		
	0/10 00/1/ 0	コントロールケーブル(14 フィート)	-	-	-	-	-	-		
	3A3-83748-0	Control Cable (14 Feet)	2	2	2	2	2	2		
	0/10 00/40 0	コントロールケーブル (15 フィート)	- 4		-	-	-	-		
	3A3-83749-0	Control Cable (15 Feet)	2	2	2	2	2	9		
	3A3 03749 0	コントロールケーフ・ル (16 フィート)	- 4	4	_	4		-		
	3A3-83751-0	Control Cable (16 Feet)		0	,	ا ا		ا ا		
	3A3-63/31-0	コントロールケープル(17 フィート)	2	2	2	2	2	-		
	242 02750 0			۱				ا؞ا		
	3A3-83752-0	Control Cable (17 Feet)	2	2	2	2	2	2		
	040 00750 0	コントロールケーブル (18 フィート)				ا ا				
	3A3-83753-0	Control Cable (18 Feet)	2	2	2	2	2	2		
	040 00754 0	コントロールケーブル (19 フィート)						١		
	3A3-83754-0	Control Cable (19 Feet)	2	2	2	2	2	2		
	040 00755 0	コントロールケーブル (20 フィート)		_	٦	ا ا	ا يا			
	3A3-83755-0	Control Cable (20 Feet)	2	2	2	2	2	2		
		コントロールケーブル (22 フィート)								
	3A3-83757-0	Control Cable (22 Feet)	2	2	2	2	2	2	<del>Kasia dilika isan</del>	
		コントロールケーブル (24 フィート)			_			<u>_</u>		
	3A3-83759-0	Control Cable (24 Feet)	2	2	2	2	2	2		
		コントロールケーブル (26 フィート)			, l			2		
	3A3-83762-0	Control Cable ( 26 Feet)	2	2	2	2	2	2	Land to the state of the state	
		コントロールケーブル (28 フィート)		250	337					
	3A3-83764-0	Control Cable (28 Feet)	2	2	2	2	2	2		
1		コントロールケーブル (30 フィート)		20				2		
	3A3-83766-0	Control Cable ( 30 Feet)	2	2	2	2	2	2		
Na man	reneed regreen and	ツインリモートコントロールホックスキット		1		1,6	27			
4-2	3A3-81301-0	Twin Remote Control Box Kit	1	1	1	1	1	1		
			-		-		-	-		
			+		-			-		
			-							
			-		-					
-			-							
						-				
-			-			-			<del></del>	
			+	-	_					
			-	-			-			
			_		الب					

# プトーハツ株式会社

#### TOHATSU CORPORATION

Address: 5-4, 3-chome, Azusawa, Itabashi-ku, TOKYO, 174-0051 JAPAN

Phone: TOKYO (03) 3966-3117 Fax: TOKYO (03) 3966-0090 Website: www.tohatsu.co.Jp

本 社 〒174-0051 東京都板橋区小豆沢 3-5-4 ℡ 03(3966)3116 マリン九州 〒812-0892 福岡市博多区東那珂 2-10-55 ℡ 092(411)8770 マリン関西 〒530-0043 大阪市北区天満 1-8-27 ℡ 06(6358)2971 マリン中部 〒440-0069 愛知県豊橋市御園町 7-12 ℡ 0532(54)5551 マリン関東 〒174-0051 東京都板橋区小豆沢 3-5-4 ℡ 03(3966)2222 マリン東北 〒981-1106 仙台市太白区柳生 2-23-1 ℡ 022(306)9131 マリン北海道 〒060-0031 札幌市中央区北一条東11丁目22-41 ℡ 011(241)8301